



# WT-RF02


COMMUNICATING WIRELESS  
ELECTRONIC DEVICE WITH  
USER INTERFACE FUNCTIONS  
FOR REMOTE CONTROL  
OF THE BOILER AND  
THERMOSTAT  
(WEEKLY SCHEDULING).

## USER GUIDE




## INSTALLATION

The REMOTE can be installed on the wall or on the table stand provided; as an alternative to wall mounting the latter allows the REMOTE to be positioned on a support.



## BRIDGE




### Legend



1 LED\_SX = left LED















## USER INTERFACE

### Display with active symbols













### Meaning of the active symbols:

| Symbol  | Description   |
|---|---|
| 1> 2> 3> 4> 5> 6>   | Heating time bands (The current one is followed by the arrow) |
| DAY<br>1  | Day of the week<br>(1 = Mon, ..., 7 = Sun)                    |
| 88:88   | Time  |
|  | Status= Winter + demand                                       |
|  | Status= Summer + demand                                       |

|   |  |
|---|--|
|  | Economy function active for domestic hot water                           |
|  | Status e Program= Off  |
|  | Program= Manual  |
|  | Program= Automatic   |
|  | Holiday function active  |
|  | Flame presence and level   |
|  | Room temperature   |
|  | Antifreeze function active   |
|  | Presence of anomaly with code  |
|  | Communication error (with boiler)  |
| <b>RESET</b>  | Boiler unlock request  |
|  | External temperature   |
|  | Assente: Bridge non associato<br>Fisso: Bridge associato e raggiungibile |
|  | Boiler communication present   |
|  | Batteries low  |

## Buttons

### Meaning of the buttons:


| <i>Symbol</i>   | <i>Description</i>             |
|---|--------------------------------|
|  | OFF/winter/summer + RESET      |
|  | Automatic/Manual program       |
|  | Programming                    |
|  | Time and day setting           |
|  | Heating temperature adjustment |
|  | DHW temperature adjustment     |
|  | User information/Settings      |
|  | Holiday function/Copy          |
|  | Value decrease                 |
|  | Value increase                 |

## INSTALLATION

The installation of the device must be carried out **ONLY** by qualified person.


**Warning:** disconnect the power to the boiler before carrying out installation

1. **Remove the front of the BRIDGE** by prying with a screwdriver at point A. Then, with the set of fastening screws supplied, secure the back of the BRIDGE making sure to run the 2 wires, coming from the boiler, inside the rectangular hole at the bottom (near the terminals). Use the terminals "OT" for the electrical connection. Using a non-polarized bipolar cable <50m (Recommended section: 2 x 0.75mm<sup>2</sup>).






2. **Refit the front of the BRIDGE.** Making sure to centre it on the rear part.


3. **Choose the most appropriate place** for installation in order to guarantee the correct device functioning. It is recommended to install the device at a height of approx. 150cm from the floor, in a place away from doors, windows or heat sources that could affect the room temperature
4. **Remove the front** of the Chronothermostat by prising with a screwdriver inside the hole below.





5. **Fix** the back of the Remote Control to the wall with the set of screws supplied.
6. **Insert** the two 1.5 V AA LR6 alkaline batteries supplied with the REMOTE, checking their correct positioning (indicated on the inside of the front).
7. **WAIT** to close the front of the REMOTE. Before turn on the boiler to power the BRIDGE.

**Note:** AUX (IN) input can be connected to a free contact, with a non-polarized bipolar cable <10m, of auxiliary remote control devices (GSM, IoT, Home Automation, Zone, ...). Closing it allows the start of pre-established states, programs and sets that can be set via parameters.






8. **Make sure** that the BRIDGE is electrically powered through the connection with the boiler board. The left LED must flash every 2 seconds.
9. **Refit the front** of the Chronothermostat making sure to centre it on the rear part.
10. **Wait** for synchronization between REMOTE and BRIDGE. The operation ends when the symbol  shown on the display stops blinking.
11. From the main screen, **press the button**  , for 10 seconds to access the RF menu. If the device has not yet been paired, the display will show “RF - -”, otherwise “RF” will appear, followed by a numerical value indicating the quality of the signal relevant to communications between the Remote and the Bridge from 0 to 4. Zero mean no signal and four mean signal present, excellent quality level.

If the symbol  is missing, remove the batteries from the Thermostat and try again from point 7. bringing the Thermostat close to the BRIDGE.




In case of a first pairing (“RF - -”), follow the pairing procedure. If, on the other hand, the device is already paired

and a new pairing is desired, first follow the unpairing procedure and then the pairing procedure, otherwise press the button   to exit the procedure.

### Unpairing procedure

1. From the current screen (“RF x”) press the button   : “de” will appear.
2. Press the button . If the unpairing is successful, “In” will appear on the screen. The device will be unpaired and it will be possible to continue with a new unpairing.
3. Press the button   to return to the main screen.





### Pairing procedure

1. From the current screen (“RF - -”) press the button:   “In” will appear.
2. Put the Bridge in standby for pairing by pressing the middle button for about 5 seconds (the left LED will start blinking). Bridge standby status lasts for 10 seconds.
3. Press the button . “>>” will appear for a few seconds to indicate that the procedure for pairing with the Bridge is in progress. If the procedure is completed successfully, the display will show “dE” together with the value of the local address received from the paired Bridge. In case of failed procedure, the indication “In” will appear again and the

procedure will have to be repeated.



4. Press the button to return to the main screen.

## DAY / TIME






1. Press the button  to set the day. The number aside the word DAY will start flashing
2. With buttons + and - set the current day of the week (day 1= Monday, ..., day 7= Sunday)
3. Press again button  to confirm and set the hour
4. Modify the value with buttons + and -, press again  to set minutes
5. After setting also the minutes using + and -, press again  to confirm everything and exit

## MODE


### **STATUS:** OFF/WINTER/SUMMER




1. **Off** - To switch off the boiler, press the button  until the icon  is displayed. See also the Hollyday function to program the Off state for a specific period of time. In any case, if the room temperature decrease below 5°C, the heating is automatically switched on again for the Antifreeze function. The production of domestic hot water depends on the type of boiler

connected.


2. **Winter** - To switch on heating, press the button  until icons  and  are displayed. Whatever boiler will deliver hot water.
3. **Summer** - To switch off the heating while maintaining the domestic hot water function, press the button  until icon  is displayed. In any case, if the room temperature decrease below 5°C, the heating is automatically switched on again for the Antifreeze function. The production of domestic hot water depends on the type of boiler connected.

### **PROGRAM:** AUTO/MAN/TEMP. MANUAL



Press the button  to change heating program from Automatic to Manual (only for Winter Status).

1. **Automatic** - When the display shows symbol  the active programme is Automatic and the Chronothermostat will work according to the set weekly programme displaying the time bands in the upper part of the screen. Press the button  to change the program from Automatic to Manual and vice versa.
2. **Manual** - When display shows symbol  the set value is fix. Use the buttons + and - to change the value by increments of 0,1 °C. To increase/decrease the set it

is necessary to keep pressed **+** for increase and **-** for decrease.

3. **Temporary Manual** - When Automatic program is active, it is possible to change temporary the set of current time band simply pressing on buttons **+** and **-**, as indicated in the Manual program. The symbol  will flash to indicate the new temporary situation which will end when the following time band starts.

#### **HEATING:** DOMESTIC HOT WATER TEMPERATURE ADJUSTMENT

1. **Heating** - Press the button : the display shows the current heating circuit water temperature setting, adjustable using the buttons **+** and **-**, in steps of 1°C.
2. **DHW** - Press the button : the display shows the current domestic hot water temperature setting, adjustable using the buttons **+** and **-**, in steps of 1°C.

Press any button to exit the menu.

## **AUTOMATIC PROGRAM**


The automatic program allows you to set up to 6 time bands per day and the corresponding room set temperatures between 7.0 ° C and 32.5 ° C, in steps of 0,1°C, from 00:00 to 23:59 in steps of 10 min, from day 1 (Mon) to day 7 (Sun).


**By default the device will follow the following preset program:**



| MONDAY-FRIDAY |       |       |       |       |       |
|---------------|-------|-------|-------|-------|-------|
| 1             | 2     | 3     | 4     | 5     | 6     |
| 06:30         | 08:00 | 12:00 | 14:00 | 18:00 | 22:30 |
| 21°C          | 18°C  | 21°C  | 18°C  | 21°C  | 16°C  |

| SATURDAY-SUNDAY |       |       |       |       |       |
|-----------------|-------|-------|-------|-------|-------|
| 1               | 2     | 3     | 4     | 5     | 6     |
| 08:00           | 10:00 | 12:00 | 14:00 | 18:00 | 23:00 |
| 21°C            | 21°C  | 21°C  | 21°C  | 21°C  | 16°C  |


#### **Automatic preset program change**

1. Press the button  to enter in program change menu



**Note:** when the program is changed the device displays first the time band 1 of day 1. Use buttons **+** and **-** to select one of the 6 time bands, use the button  to change the days of the week.

2. Press the button  to move between starting time, temperature set and time bands.
3. Press buttons **+** and **-** to change start time by increments of 10 minutes
4. Press the button  to change temperature set
5. Press buttons **+** and **-** to change the temperature by

increments of 0,1°C

6. Press the button  to go back to time bands
7. Press buttons + and - to move to the next/previous time band (the selected time band is followed by the arrow)



Wait 60 seconds to exit or press any other button After having set the program for one day of the week, it is possible to copy it on the next days:

8. Use button <sup>DAY</sup> to select the day of the week to copy
9. Press button  to copy the settings of the selected day of the week to the next day

## SPECIAL FUNCTIONS

**HOLIDAY FUNCTION** - is used to switch off heating (the deactivation of the domestic hot water depends on the type of boiler connected) from 1 hour to 45 days, adjustable in steps of 1 hour. At the end of the function the previous settings are activated. If the room temperature decrease below 5°C, the heating is automatically switched on again for the Antifreeze function.


### **Activation and setting of Holiday function:**

1. Press button . The symbol  starts flashing and the hours and minutes become -00:01, which is the time remaining before the end of the Holiday function.

2. Press buttons + and - to extend the time remaining until the end of the Holiday function in 1 hour increments (-00:01 means 1 hour; -45:00 means 45 days). By keeping the button pressed the time and days will change rapidly.
3. During the Holiday function the display will continue to show the time remaining until the end of the function.

To turn off Holiday function press the button .

## USER PARAMETER EDITING

- Press the button  for 3 seconds to access user parameters menu
- Press any other button to exit

## CU - SLIDING TEMPERATURE - COMPENSATION CURVE


**Note:** default point set is 0


Installing the external probe to the boiler the heating system temperature is adjusted according to the outside weather conditions. In particular, as the external temperature increases the system delivery temperature decreases according to a specific compensation curve.

The compensation curve can be set from 1 to 10



according to the following graph:




1. Press the button  for 3 seconds until CU is showed
2. Press buttons + and - to change the value



*Set the compensation curve to 0 to disable Sliding Temperature adjustment.*

### SLIDING TEMPERATURE - PARALLEL CURVE OFFSET


**Note:** default point set is 30°C

Once the Compensation curve has been set, parallel curve offset can be adjusted from 20 to 40 as shown in the following graphs:



1. Press the button  for 3 seconds until CU is showed
2. Press again  until OF is showed
3. Press buttons + and - to change the value


### P1 - ENABLE DHW PROGRAMMING


To set the weekly automatic programme proceed as described in the section “AUTOMATIC PROGRAM”. During the COMFORT level, the boiler will maintain the domestic hot water set; during the ECO level, showed on the display by the symbol , the production of domestic hot water depends on the type of boiler connected. Refer to the boiler instructions.

**Attention:** Make sure the remote control is set to Winter mode with automatic operation.

**Note:** default point set is 0= Deactivated.

#### Program setting:

1. Press the button  for 3 seconds until CU is showed

2. Push the button  2 times to switch on P1
3. Press buttons + and - to change the value  
0= Deactivated  
1= Auto



## **P2 - PRE-HEATING FUNCTION**

**Important:** *this function is active only if heating automatic mode has been selected.*

When this function is enabled, the device makes the boiler starting before the set hour, in order to reach comfort temperature the soonest even from the very beginning of the time slot (not before 00:00). It is also possible to set a fixed pre-heating slope, in this way, the device considers as comfort temperature adding 3° to set temperature, thus the boiler does not switch off when the set is reached. During the pre-heating function the room temperature °C symbol flashes. The function ends when the difference between the programmed room temperature and the actual one is less than 0,5°C.

**Note:** *default point set is 0= Deactivated*

### **Function setting:**

1. Press the button  for 3 seconds until CU is showed
2. Push the button  3 times to switch on P2



3. Press buttons + and - to change the value:  
0= Deactivated  
1= Automatic pre-heating  
2= Fixed pre-heating slope

## **P3 - NUMBER OF TIME BANDS**

The Automatic programme manages 6 points, each of them associated to an hour and a temperature. Each point matches to the beginning of a new time band. If necessary they can be reduced to a minimum of 2.



**Note:** *default point is set to 6*

### **Function setting:**

1. Push the button  for 3 seconds until CU is showed
2. Push the button  4 times to switch on P3
3. Press buttons + and - to change the value




## **P4 - HEATING MINIMUM TEMPERATURE**

**Setting the minimum heating circuit water temperature by step of 1°C:**

1. Push the button  for 3 seconds until CU is showed
2. Push the button  5 times to switch on P4
3. Press buttons + and - to change the value



## P5 - SYSTEM FILLING

This function manages the operation mode of the electric device for filling the water circuit in certain boiler models.

**Attention:** Set the boiler control to manual filling. In manual mode, if the sensor installed in the boiler detects insufficient pressure, the bar icon will flash on the display; press the button    to activate the special solenoid valve. During manual or automatic system filling the bar icon will become fixed. Once the nominal pressure is restored, the remote control will return to the normal display.

**Note:** default point set is 0= Deactivated.


### Function setting:


1. Push the button  for 3 seconds until CU is showed
2. Push the button  6 times to switch on P5
3. Press buttons + and - to change the value:

## P6 - TEMPERATURE MEASUREMENT UNIT (°C/°F)

**Note:** default point is set to 0=°C.

### Temperature setting:

1. Push the button  for 3 seconds until CU is showed



2. Push the button  7 times to switch on P6
3. Press buttons + and - to change the value:  
0= °C  
1= °F

## P7 - CORRECTION OF ROOM TEMPERATURE READING


It is possible to correct the room temperature reading between -2°C and +2°C by steps of 0,1°C.

**Note:** default point is set to 0.

### Setting of reading correction:

1. Push the button  for 3 seconds until CU is showed
2. Push the button  8 times to switch on P7
3. Press buttons + and - to change the value




## P8, P9 - IPHONE CONTACT INPUT (GSM)

Normal Remote Control operation is ensured as long as the telephone contact remains open. The closing of this contact, indicated on the display with the symbols , can be used to force the Remote Control to switch off heating or to set the room temperature to a preset fixed value.

**P8 - note:** default point is set to 0= Heating switched off

**P9 - note:** default point is set to 20°C



**Function setting:**

1. Push the button  for 3 seconds until CU is showed
2. Push the button  9 times to switch on P8
3. Press buttons + and - to change the value:
4. 0= to switch off heating when the contact is closed
5. 1= to adjust room temperature to a preset fixed value (by means of parameter P9) when the contact is closed.
6. Push the button  to switch on P9
7. Press buttons + and - to change the value (only if parameter P8 is set to 1)


**OT - TYPE OF COMMUNICATION PROTOCOL**

Parameter reserved for qualified person.

**Parameter setting:**

1. Press the button  for 3 seconds until CU is showed
2. Push the button  11 times to switch on OT
3. Press buttons + and - to change the value:  
0 = Standard  
1 = OEM  
2 = B&P

**GENERAL INFORMATIONS**

The remote control can provide the user with information on boiler status. Each press of the button  allows the cyclic display of the following information:

- T1 - Heating circuit delivery water temperature
- T2 - Domestic hot water temperature
- T3 - Heating circuit return water temperature (boilers with sensor only)
- T4 - Delivery water temperature setpoint calculated by the remote control
- P5 - Actual burner power
- F6 - Actual fan speed (condensing boilers only)
- F7 - Actual DHW flowrate (instant hot water boilers with flowmeter only)
- P8 - Actual system pressure (boilers with pressure sensor only)
- M - Device model
- V - Device software version

**FAULTS**

- **E91** = communication error with the boiler
- **E92**= room temperature reading probe not working
- **E93**= external temperature reading probe not working
- **AXX** = anomaly XX of the boiler not unlockable
- **FXX** = anomaly XX of the unlockable boiler

## RESTORING FACTORY SETTING

**Important:** with this procedure the device parameters will be restored to the factory set values, except for the time and day setting.

To reset user setting will be necessary to push the buttuns **+** and **-** together for 10 seconds (the message RE flashing is displayed).

## TECHNICAL CHARACTERISTICS AND DEFAULT SETTINGS

|                        |            |
|------------------------|------------|
| Time                   | 12:00      |
| Day                    | 1 (monday) |
| Mode                   | Auto       |
| Heating manual temp    | 20°C       |
| Antifreeze temperature | 5°C        |

## PRODUCT DATASHEET

According to 811/2013 Rule, the class of temparture controller is:

| Class | Contribution to seasonal space heating energy efficiency in % | Description                                       |
|-------|---|---|
| V     | +3%   | Chronothermostat                                  |
| VI    | +4%   | Chronothermostat combined with the external probe |

The WT-RF02 remote controls are compliant with:

• **2014/30/UE**  
(Electromagnetic Compatibility Directive)

WT-RF02 must comply to the above mentioned Directive, so CE mark is printed on the user manual:





**WARMHAUS Isıtma ve Soğutma Sistemleri San. Tic. A.Ş.**

Taşpınar Mahallesi, TEKNOSAB 1. Cadde No: 12

16700 Karacabey / BURSA

**T** +90224 295 94 00 **F** +90 224 411 23 77

info@warmhaus.com.tr

**www.warmhaus.com**

Although this manual has been written with the maximum attention and care, we do not exclude any possible mistakes, incomplete or incorrect data. The constructor reserves the right to change the products specifications or to stop the production of the same without any previous advice and to include or supply new functions or new instructions of the products already sold. The constructor cannot be held responsible for any losses or damages, direct or not, that can originate from the use of the products.